









Thank you for purchasing your Soundmatters DASH A! For more information, visit Soundmatters.com/dasha, email support@soundmatters.com, or call 800.698.7662.




Connect Your DASH A comes ready to Bluetooth pair, with the LED flashing blue/yellow. If it is not, hold the Power Button for 5 seconds.







Buttons and Inputs Guide



LED Indicator (Flashes Blue for Bluetooth, White for Audio In):

Blue (0.5 sec) / Yellow (0.5 sec): Bluetooth Pairing Mode Blue or White (2 sec) / Off (3 sec): On and Connected

Red (2 sec) / Off (3 sec): Low Battery

Blue or White (2 sec) / Red (3 sec): Battery Charging

Blue or White (2 sec) / Green (3 sec): Battery Charging Complete